



RED LED mounts on 48v switch top 2 legs with Anode (long leg) on the leg closest to PCB edge.

RP = Resistor to set PAD attenuate level
 RL = Resistor load for input transformer secondary loading
 CL = Capacitor load for input transformer secondary loading
 RZ = Resistor part of zobel load for input transformer secondary loading
 CZ = Capacitor part of zobel load for input transformer secondary loading
 RG = Sets maximum gain of mic pre amp



<http://www.jlmaudio.com>

Title		
Baby Animal Mic Pre with JLM14 & JLM99v or Hybrid		
Size	Number	Revision
A4		A
Date:	25-Apr-2006	Sheet of 1
File:	H:\Documents and Settings\Hosef\Desktop\JLM Audio\JLM Schematics\BA9899-1.DDD	