



Only add diode and 9v battery if battery power is needed  
 When Phantom power is applied it will automatically turn the battery off

Title		
<b>JLM DI Kit Phantom Powered Transformer Out Schematic</b>		
Size	Number	Revision
A4		
Date:	28-Feb-2005	Sheet of
File:	C:\Program Files\ADVSCHEM\Previous Backups\JLM DI phantom power simple.DDB	